

## MAIN FEATURES

- ✓ Eco-friendly: low power consumption, easily reparable
- ✓ Easy to use
- ✓ Thin and light
- ✓ Flexible and portable




Fig. 1: Sensor illustration

## GENERAL DESCRIPTION

The strain sensor was developed in the Engineering Physics Department at INSA Toulouse. It is based on the article "*Pencil Drawn Strain Gauges and Chemiresistors on Paper*" by Cheng-Wei Lin, Zhibo Zhao, Jaemyung Kim, and Jiaying Huang, published in 2014. This sensor consists of a small piece of paper coated with a graphite layer from a pencil.

When the paper is deformed, the number of connected graphite particles in the thin layer changes. This variation is directly related to the type of deformation, resulting in a change in resistance and conductance. This allows us to measure deformation, like a traditional strain gauge.

The structure of the graphite layer varies depending on the type of pencil used. We conducted tests with two types of pencils: HB (medium hardness) and 2B (softer). To achieve this, our sensors were coupled with a transimpedance amplifier and an Arduino Uno, all mounted on a PCB.

## PIN CONFIGURATION

Pin number	Usage
1	$V_{in}$
2	$+V_{CC}^*$

\*Typically, a +5 V voltage




Fig. 2: Top view dimensions (in mm)

## STANDARD USE CONDITIONS

Pin number	Unit	Typical value
Temperature	°C	$20 \pm 10$
Humidity	%	$45 \pm 15$
Air quality	%N <sub>2</sub> /O <sub>2</sub>	80/20

## TECHNICAL SPECIFICATIONS

Type	Strain sensor
Materials	Graphite (4B to 2H pencils)
Sensor type	Passive: power supply required
Power supply	+5 V
Nature of output signal	Analog
Nature of measurand	Voltage
Typical response time	Less than 50 ms
Typical use	Evaluation of a compression or a tension deformation

## ELECTRICAL CHARACTERISTICS

Pencil type	Unit	Value		
		Minimum	Typical	Maximum
HB	MΩ	200	220	380
2B	MΩ	2	2,3	3

## TYPICAL PERFORMANCE CHARACTERISTICS




Fig. 3: Characteristics in tension




Fig. 4: Characteristics in compression

## TYPICAL APPLICATION




Fig. 5: Transimpedance amplifier circuit in order to use the sensor

The strain sensor is connected to a transimpedance amplifier circuit (in order to collect a readable signal for the Arduino Uno). The latter is composed by low- and high-pass filters to cancel the different noises (amplification, current and the “50 Hz component” due to the electric network).

The component B represents a variable resistor. It is used to match amplification of circuit for each type of pencil.

Finally, it is possible to know the value of the resistance of our *GazouTech™ GT-LTGSJ24* with the following formula:

$$R_{sensor} = R_1 \left( 1 + \frac{R_3}{R_{variable}} \right) \frac{V_{cc}}{V_{adc}} - R_1 - R_5$$